



AIRTHINGS

Parkveien 53b, NO-0256 Oslo
Norway
www.airthings.com

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Airthings is under license.

Treehouse 14004-05-3-021

Corentium Pro

by Airthings



CONTINUOUS RADON MONITOR QUICK START GUIDE



A START A MEASUREMENT

- Insert the batteries. A measurement is started automatically.
- To start another measurement either:
 - press the button A indicated in the Figure,
 - or schedule a new measurement in the App.
- Allow 45 seconds for a self test phase.

B BLUETOOTH CONNECTION

Corentium PRO app is the default tool for analysis and reporting.

- Search for Corentium PRO app in the App Store / Google Play.
- Open the Corentium PRO app. In the first screen, wait until the monitor is discovered and it appears in the list of devices; then, select the monitor and connect. Configure your profile in Settings&Profile.
- The reporting option can be used after 24 hours of measurement.

C STATUS LIGHTS (LEDS)

- *Flashing green, yellow and red:* Monitor self-test.
- *Flashing green:* Operation mode.
- *Flashing yellow:* Attention. Connect to the Corentium PRO app for instruction.
- *Flashing red:* Error. Connect to the Corentium PRO app for instructions.
- *Blue flash and beep:* Bluetooth connect.
- *Blue flash (once):* Bluetooth disconnect.
- *Continuous blue:* USB connected.

1 KENSINGTON LOCK

For securing the monitor from theft, being moved during measurement, etc.

2 USB CONNECTION

CRA PC software is an optional analysis and reporting tool.

- Open CRA PC Software (refer to Installation Guide and Software Manual).
- Connect monitor to PC via USB.

3 BATTERY COMPARTMENT

Use a torx 6 screw driver to open battery compartment.

4 TRIPOD MOUNT THREAD

5 CALIBRATION LABEL

6 SERIAL NUMBER LABEL